

## STANDARD OPERATING PROCEDURE DOCUMENT

Title		Logging onto the UPS Web I	Doc. No.	IT120			
Scope		IT Department					
Purpose		To ensure the IT department can log onto the UPS web management system to configure the UPS.					
UPSGUIDELINESThe UPS provides support to the server and computer infrastructure within the call centre in the event of loss of power to the Wavertree call centre. The web access system provides access to monitor the status of the UPS and configure the SMTP settings to allow automatic alerts to be sent out in the event of failure to the UPS.							
PROCEDURE				RESPONSIBILITY			
1	To logon to the UPS system enter the following IP address in the Web IT Department browser. <u>http://192.168.110.15</u>						
2	Once the page displays you will then be required to enter a username and password. For the username and password please refer to the IT shared drive for the user credentials.			IT Departm	ent		
3	Once you have entered the password click the <b>login</b> button IT Department				ent		
4	After clicking the login button a new window will then display. You will have access to check the server <b>Status</b> , view the <b>Event Log</b> , configure the <b>Network, UPS</b> and <b>Services Installed</b> and change the <b>Logon credentials</b> for the UPS.				ent		

5	It is recommend not to make any changes to the UPS without consulting the supporting company. For standard changes including <b>Network</b> , <b>Date and Time</b> and <b>SMTP</b> settings follow the procedures below.	IT Department
6	If you require to change the SMTP details to send out email alerts hover over the <b>Config</b> button and then Scroll down to <b>Services</b> , when a further window opens click the <b>Email</b> button.	IT Department
7.	<ul> <li>When the new window displays you can enter SMTP details of the SendGrid server to pass on the auto alerts. When configuring the UPS email you will enter a sender address and an email address of the person who will be receiving the emails.</li> <li>Using the box below you can select the type of emails you want the user to receive.</li> <li>Please not the UPS cannot send emails to distribution groups.</li> </ul>	IT Department
8.	To alter the <b>Network</b> details, hover over the <b>Config</b> button until the new menu displays and then click on the <b>Network</b> button. You will then have access to alter the hostname and Network configuration. Currently the UPS is configured to the static I.P address <b>192.168.110.15</b>	IT Department
9.	To alter the Time and Date of the UPS hover over the <b>Config</b> button until the new menu displays and then click on the <b>Date and Time</b> button. You will then have the option to enter the new time and date. Further configuration can be made to sync the UPS time and date settings with the domain server.	IT Department
10.	If there are any failings on the UPS or the main power drops you can view the occurrence of events by viewing the Event Log maintained on the UPS.	IT Department
11.	If you require any further support please contact TSE Ltd or Ingram Installations.	IT Department



## STANDARD OPERATING PROCEDURE DOCUMENT

Title	SOP IT120 Logging onto the UPS Web Management System		Doc. No.	IT120
Version		V1	-	-

Approving Managers/Committee							
Date Ratified							
Department of Originator				Information Management and Technology			
Responsible Executive Director				Director of Finance			
Responsible Manager/Support				Head of IT			
Date Issued				11/11/2015			
Review Date				November 2016 or when there is a change in the process.			
Target Audience				All Staff			
Version	Date	Conti	rol Re	eason Accountable Version		Accountable Person for this Version	
			1				
Reference documents				Electronic Locations	Location	ons for Hard Copies	
Urge Clini			Urge Clinio F	nt Care 24 Intranet / SOPs / * cal Operations Admin section Please delete as appropriate *	Standard Operating Procedures File in the Call Centre.		
Document Status: This is a controlled document. Whilst this document may be printed, the electronic version maintained on the UC24 Intranet is the controlled copy. Any printed copies of the document are not controlled.							